
Low-power Wide-dynamic-range Readout System for a 64-channel Multi-anode PMT of a Scintillation Gamma Camera

Satoru Iwaki

T. Tanimori, H. Kubo, K. Miuchi,
S. Kabuki, J. Parker, H. Nishimura, K. Hattori,
K. Ueno, S. Kurosawa, C. Ida, M. Takahashi,
N. Higashi, K. Nakamura, T. Sawano, K. Taniue

***Dept. of Physics, Graduate school of Science, Kyoto
University, Kyoto, Japan***

11th iWoRiD, Prague, Czech Republic

Contents

- Introduction
 - Electron Tracking Compton Camera (ETCC)
 - Scintillation camera
- New Readout System
 - Evaluation
- Performance of Scintillation Camera
 - GSO(Ce) Array
 - Single Crystal of a LaBr₃ (Ce)
 - LaBr₃ (Ce) Array
- Summary and Future work

Electron Tracking Compton Camera (ETCC)

Sub MeV~ MeV gamma-ray
imaging for ...



- Astronomy (balloon experiment, SMILE)
- Medical Imaging


■ **micro-TPC**

- Gaseous Time Projection Chamber
Based on μ -PIC as readout system
=>Track and energy of recoil electron





■ **Scintillation Camera**

- Pixel Scintillator Array
+Multi Anode PMT
=>Position and energy of
scattered gamma-ray



Reconstruct Compton Process
Determine direction and energy of
incident gamma ray event by event






2 source image (^{137}Cs (662keV)
and ^{54}Mn (835keV))


Scintillation Camera

Pixel Scintillator Array (PSA)

- GSO(Ce) crystal
- array : 8×8
- Pixel size : $6 \times 6 \times 13\text{mm}^3$
- Pixels are optically isolated with the ESR(3M)




PSA is optically glued to H8500 with OKEN-6262A grease



Multi Anode PMT H8500 (HPK)

- anode : 8×8
- Size : $52 \times 52 \times 20\text{mm}^3$
- Effective area:
 $49 \times 49\text{mm}^2(89\%)$
- Gain : $\sim 10^6 @ -1000\text{V}$
- Gain uniformity : $\sim 1:3$



Signal size
 $\sim 500\text{pC} @ 1\text{MeV}$

SMILE

Sub-MeV gamma-ray Imaging Loaded-on-balloon Experiment


SMILE-1 (Sep. 1st, 2006)

- $10 \times 10 \times 15\text{cm}^3$ TPC 33 Scintillation Cameras
- Operation test of our ETCC@ 35km
- Background Measurement
(Diffuse cosmic and atmospheric gamma)

SMILE-1 has been successful.

Scintillation camera

- Anode signal is grouped by chained resistor.
- Measured by discrete NIM/VME modules
Energy Resolution : 11% @ 662keV (FWHM)
- Dynamic range : 80keV ~ 800keV
- Power Consumption : 2.7W/64pixels



SMILE-2 (2011)

- $(40\text{ cm})^3$ TPC + 192 Scintillation Cameras
- Observation of Crab or Cyg X-1

We are developing
a larger detector.

Requirements for scintillation camera

- Position resolution
 - Energy resolution
 - Dynamic range
 - Radiation hardness
 - Power consumption
- Affect the angular resolution of Compton Camera
- Affect the dynamic range of Compton Camera
- Scintillator is activated with cosmic ray in the sky.
- Power is limited in the sky.

	Number of MAPMT	Power Consumption [W/64pixels]	Energy Resolution (FWHM)@662keV	Dynamic Range [keV]
SMILE-1	33	2.7W	~ 11.0%	80-800
SMILE-2	192	< 400mW	~ 11.0%	80-1000

We have improved new readout system with low power consumption.


Readout system with ASIC (VA/TA)

CP80168 (Clear Pulse)

- 32ch CMOS ASIC (by IDEAS ASA) *2
- 64ch readout
- Input dynamic range : ~35pC
- 80 us/64ch to read out
- Power Consumption : 1.05W



15cm





- Energy Resolution : ~11% @662keV (FWHM)
- Dynamic range : 30keV~800keV

- Narrow input dynamic range
- Large power consumption.

New Readout System


Head Amp Unit CP80190 (Clear Pulse)

- 64ch readout
- Using only **discrete devices**.
- **Input dynamic range is variable** by replacing feedback capacitor.
(Adjusted to $<750\text{pC}$)
- Power Consumption: 1.2W
- 20s/64ch to read out



Linearity of CP80190

- Input some test charge into CP80190






Linearity is kept from 50pC to 700pC ($\pm 0.5\%$)
 \Rightarrow Enough for our Scintillation Camera.

GSO + CP80190

Reconstructed image and spectra

^{137}Cs




- Reconstructed by Center of Gravity Method.
- Each 64 pixel is clearly resolved


GSO + CP80190

Energy Resolution and Dynamic range

Energy VS Resolution




- Energy Resolution (average):
10.6% @ 662keV (FWHM)
- Dynamic range : **30keV ~ 1.3MeV**
- Power Consumption : 1.55W/PMT



=> Too large power consumption for SMILE-2

Chained Resistors + CP80190

In order to reduce further the power consumption...






The number of readout ch is reduced to 1/16
 => total power consumption is reduced.

Chained Resistors + CP80190

Reconstructed image and spectra

^{137}Cs




• Each 64 pixel is clearly resolved


Chained Resistors + CP80190

Energy Resolution and Dynamic range

Energy VS Resolution



- Energy Resolution (average):
10.5% @662keV(FWHM)
- Dynamic Range: 80keV~1300keV
- Power Consumption: 100mW/PMT



=> Satisfy all requirements
of SMILE-2

LaBr₃(Ce) Scintillator


For next experiment after SMILE-2, or medical imaging,
It is important to improve angular resolution of ETCC.




Saint-Gobain
BrillanCe380
Size: ϕ 38 × 38mm

⊙ Excellent Energy Resolution
: $\sim 3\%$ @ 662keV (FWHM)

× Strong Hygroscopic



- Pixel size : $5.9 \times 5.9 \times 20\text{mm}^3$
- 8×8 array
- Glass window :
Quartz (t 2.3 mm)
- Hermetic package :
Aluminum (t 0.5 mm)



Energy Resolution measured with
discrete NIM/VME modules is
 5.8% @ 662keV (FWHM)



CP80190 + LaBr₃ (single crystal)



Single Crystal
(ϕ 13 × 13mm)

Single Anode PMT
(HPK R6231)




- Energy Resolution :
3.4% @ 662keV (FWHM)
(consistent with NIM/VME
discrete readout system)
- Dynamic range : 80keV ~ 1.3MeV



CP80190 + LaBr₃ Array

Reconstructed image and spectra




¹³⁷Cs



• Each 64pixel is clearly resolved

CP80190 + LaBr₃ Array

Energy Resolution and Dynamic range



- Energy Resolution (average):
5.4% @ 662keV (FWHM)
- Dynamic Range:
80keV-800keV

Summary ~For SMILE-2~

- We have developed ETCC which consists of gaseous TPC and scintillation camera.
- For next balloon experiment, we have developed a new readout system of scintillation camera with very low power-consumption and wide dynamic-range.

	Energy Resolution (FWHM@662keV)	Energy Dynamic range	Power (/PMT)
Requirements	11%	80keV~1MeV	400mW
Chained resistor and discrete NIM/VME modules	○11%	△80keV~ 800keV	× 2.7W
CP80168 (VA/TA) (64ch readout)	○11%	△30keV~ 800keV	× 1.4W
CP80190 (64ch readout)	○10.6%	◎30keV~ 1.3MeV	× 1.5W
Chained resistor and CP80190 (4ch readout)	○10.5%	◎80keV~ 1.3MeV	◎100mW

Future Work

- For SMILE-2
 - Enlargement of the scintillation camera.
 - Install readout system in DAQ system of ETCC.
- In order to improve angular resolution of ETCC. (for Medical imaging and next to SMILE-2)

We have developed LaBr₃ arrays.

- Energy resolution of the array (FWHM, @662keV)
 - Discrete modules (4ch readout) : 5.8 %
 - New readout system (64ch readout) : **5.4%**
- Dynamic range : 80 - 800 keV

Thank you